


TP-LINK ARCHER C20 - KONFIGURACJA ROUTERA - PPPOE


Aby rozpocząć konfigurację routera, należy uzyskać z nim połączenie, wybierając jedną z opcji:

- **połączenie przewodowe** - *kabel internetowy pomiędzy gniazdem ethernet w komputerze, a portem LAN w routerze (gniazdo oznaczone kolorem żółtym),*
- **Wi-Fi** - *nazwa sieci bezprzewodowej (SSID) oraz domyślne hasło (Wireless Password) widnieją na naklejce na odwrocie routera.*

Po połączeniu z routerem, pierwszym krokiem jest zalogowanie się do opcji konfiguracyjnej routera - należy otworzyć przeglądarkę internetową, a w polu adresowym wpisać <http://tplinkwifi.net> lub adres **192.168.0.1**.



Następnie należy zalogować się do konfiguracji routera - w tym celu należy wpisać domyślne dane dostępowe, znajdujące się na naklejce na odwrocie routera (domyślne dane to *admin/admin*).

A screenshot of a login form. It consists of two input fields stacked vertically. The first field has a user icon and the text 'admin' inside. The second field has a key icon and several dots representing a password. Below the fields is a teal button with the text 'Log In' in white.

Nie mylić z danymi dostępowymi do sieci bezprzewodowej!


Po pomyślnym zalogowaniu, należy wybrać pozycję **Szybka konfiguracja/Quick Setup** z kolumny po lewej stronie i przejść dalej.

The screenshot shows the TP-Link Archer C20 Quick Setup interface. The left sidebar contains a menu with the following items: Status, Quick Setup (highlighted in yellow), Operation Mode, Network, Dual Band Selection, Wireless 2.4GHz, Wireless 5GHz, Guest Network, DHCP, Forwarding, Security, and Parental Controls. The main content area is titled "Quick Setup - Start" and contains the following text: "Run the Quick Setup to manually configure your internet connection and wireless settings. To continue, please click the Next button. To exit, please click the Exit button." At the bottom right, there are two buttons: "Exit" and "Next" (highlighted in green).

Pierwszy krok to wybranie trybu routera. Należy zaznaczyć **Router bezprzewodowy/Wireless Router** i przejść dalej.


The screenshot shows the TP-Link Archer C20 Quick Setup interface at the "Operation Mode" step. The left sidebar menu is the same as in the previous screenshot, but "Quick Setup" is no longer highlighted. The main content area is titled "Quick Setup - Operation Mode" and contains the following text: "Choose Operation Mode:" followed by three radio button options: "Wireless Router" (selected with a blue dot), "Access Point", and "Range Extender". Below the "Wireless Router" option, there is a description: "Share Internet connection from an Ethernet cable. For example, hotel room, small office...". At the bottom right, there are two buttons: "Back" and "Next".

W kolejnej części konfiguracji, należy wybrać opcję **PPPoE** i przejść dalej.



The screenshot shows the configuration page for the TP-Link AC750 Wireless Dual Band Router (Model No. Archer C20). The left sidebar contains a menu with options: Status, Quick Setup, Operation Mode, Network, Dual Band Selection, Wireless 2.4GHz, Wireless 5GHz, Guest Network, DHCP, Forwarding, Security, Parental Controls, Access Control, Advanced Routing, Bandwidth Control, IP & MAC Binding, Dynamic DNS, IPv6, and System Tools. The main content area is titled "Quick Setup - WAN Connection Type". It includes a note: "The Quick Setup is preparing to set up your internet connection, please choose one type below according to your ISP. The detailed description will be displayed after you choose the corresponding type." Below this, there are radio button options: Auto-Detect, Dynamic IP (Most common option), Static IP, and PPPoE/Russia PPPoE (which is selected). A note below the options states: "You have DSL connection and is connected via PPPoE (Broadband Connection) on your computer or existing router." There are also options for L2TP/Russia L2TP and PPTP/Russia PPTP, with a note: "Note: For users in some areas (such as Russia, Ukraine etc.), please contact your ISP to choose connection type manually." At the bottom, there is a checkbox for "More Advanced Settings" and two buttons: "Back" and "Next".

Następnie należy wpisać dane do konta PPPoE, które dołączone są do umowy i przejść dalej.



The screenshot shows the configuration page for the TP-Link AC750 Wireless Dual Band Router (Model No. Archer C20). The left sidebar contains a menu with options: Status, Quick Setup, Operation Mode, Network, Dual Band Selection, Wireless 2.4GHz, Wireless 5GHz, Guest Network, DHCP, Forwarding, Security, Parental Controls, Access Control, Advanced Routing, and Bandwidth Control. The main content area is titled "Quick Setup - PPPoE". It includes a note: "Please enter the Username and Password. If the Username/Password are unknown, please contact your ISP." Below this, there are three input fields: "Username:", "Password:", and "Confirm password:". At the bottom, there is a "Secondary Connection:" section with radio button options: Disabled (which is selected), Dynamic IP, and Static IP (For Dual Access). At the bottom, there are two buttons: "Back" and "Next".


W kolejnym kroku, należy zaznaczyć oba widoczne pasma, aby router udostępniał sieci bezprzewodowe w dwóch częstotliwościach i przejść dalej.

The screenshot shows the TP-Link Archer C20 Quick Setup interface. The left sidebar contains a menu with options: Status, Quick Setup (highlighted), Operation Mode, Network, Dual Band Selection, Wireless 2.4GHz, Wireless 5GHz, Guest Network, DHCP, Forwarding, Security, and Parental Controls. The main content area is titled "Quick Setup - Wireless Dual Band Selection" and includes the instruction: "Please select or clear the check box to enable or disable a given radio band." Below this, there are two checked checkboxes: "2.4GHz" and "5GHz". At the bottom right, there are "Back" and "Next" buttons.

Kolejnym krokiem jest konfiguracja sieci bezprzewodowych. Nazwa sieci bezprzewodowej (SSID) oraz hasło (password) nie muszą być zmieniane. Jeśli będą jednak edytowane, należy pamiętać, aby odróżnić je od siebie - na przykład poprzez dodanie końcówki **_5G** na końcu nazwy sieci bezprzewodowej działającej w częstotliwości 5GHz. Hasło do sieci bezprzewodowej może być dowolne, jednak musi zawierać minimum 8 znaków.

The image shows two side-by-side configuration screens. The left screen is for "Wireless 2.4GHz" and the right is for "Wireless 5GHz". Both screens have the following fields: "Wireless Network Name" (with values "TP-Link_9999" and "TP-Link_9999_5G" respectively), "Security" (with "WPA2-PSK (Recommended)" selected), and "Wireless Password" (with value "12345678"). Both screens also have "More Advanced Wireless Settings" checkboxes and "Back" and "Next" buttons at the bottom.

Ostatnia część konfiguracji to podsumowanie wprowadzonych wcześniej danych. Konfigurację kończy użycie przycisku **Zapisz/Save**.

 **AC750 Wireless Dual Band Router**
Model No. Archer C20

Status

Quick Setup

Operation Mode

Network

Dual Band Selection

Wireless 2.4GHz

Wireless 5GHz

Guest Network

DHCP

Forwarding

Security

Parental Controls

Access Control

Advanced Routing

Bandwidth Control

IP & MAC Binding

Dynamic DNS

IPv6

System Tools

Logout

Quick Setup - Confirm

The Quick Setup is complete. Please confirm all parameters below. Click BACK to modify any settings or click SAVE to save and apply your configurations.

Parameters Summary:

| | |
|------------------------------|-----------------|
| Connection Type: | PPPoE |
| Username: | xxx |
| Password: | *** |
| Secondary Connection: | Disabled |
| Wireless 2.4GHz: | Enabled |
| Wireless Network Name(SSID): | TP-Link_9999 |
| Channel: | Auto |
| Mode: | 11bgn mixed |
| Channel Width: | Auto |
| Security: | WPA2-Personal |
| Wireless Password: | 12345678 |
| Wireless 5GHz: | Enabled |
| Wireless Network Name(SSID): | TP-Link_9999_5G |
| Channel: | Auto |
| Mode: | 11a/n/ac mixed |
| Channel Width: | Auto |
| Security: | WPA2-Personal |
| Wireless Password: | 12345678 |